

TENNIS COURT LINE MARKING PACK - INSTRUCTIONS

Please read MSDS sheets prior to application enclosed in box with Tennis court drawing dimensions

Open box this side up and read MSDS sheets



Application: DO NOT PAINT ON DAMP OR WET SURFACES. The surface must be clean and dry before applying coating to surface. Please ensure the temperature is 15 degrees C or above before application. Do not apply if rainfall is imminent.

Empty all contents of box

Flat pack the box to use as a movable ground protector

Fit pole into extension fitting

Fix roller frame to handle

Secure both extension fitting and pole to handle with masking tape.

Lay spacers on existing lines or form new lines as per drawing

Lay masking tape to either side of spacers - Walk on the tape to ensure good adhesion.

Paint between each line within 15-20 minutes of laying tape. This may mean doing the court in sections or one line at a time.

When ready to apply coating -

Empty the contents of the box, flat pack the box

Lay flat pack box adjacent to masking tape to prevent drips/spills on tennis court surface

Put on the gloves provided - Mix or stir paint prior to application

Place can on flat packed box- Cut black plastic fitting on lid clasp - Open clasp on lid

Remove lid from can placing on flat pack box

Gently roll sleeve across top of paint in can

Then apply paint between masking lines

When each line completed, re-coat if necessary after 15-20 minutes.

It is best to complete half of the court at a time before embarking on the other side of the net.

When all line marking complete, reassemble flat pack box and place all used masking tape in box for disposal. Dispose empty can and waste material responsibly.

Tennis Court DIY Supplies

Tel UK 0044 028 9092 3412

Tel IRE 00353 01 844 7008

Email: sales@tenniscourtdiysupplies.com

www.tenniscourtdiysupplies.com

